



Service Information

ix35 Diesel

Mileage based service



CUSTOMER NAME	
VEHICLE REGISTRATION	
VIN (VEHICLE IDENTIFICATION NO.)	
MILEAGE	
DATE	

KEY	L = LUBRICATE	MILES	20,000	40,000	60,000	80,000	100,000	120,000	140,000	160,000
R = REPLACE	A = ADJUST	MONTHS	12	24	36	48	60	72	84	96
I = INSPECT	C = CARRY OUT	YEARS	1	2	3	4	5	6	7	8

ENGINE BAY										
ENGINE OIL & FILTER	R	R	R	R	R	R	R	R	R	R
AIR CLEANER	Inspect every 20,000 ; Replace every 40,000									
FUEL FILTER	Inspect at 20,000 ; Replace every 40,000									
UNDER BONNET FLUID LEVELS	I	I	I	I	I	I	I	I	I	I
ALTERNATOR VACUUM PUMP		I		I		I		I		I
ALTERNATOR OIL HOSE & VACUUM HOSE		I		I		I		I		I
VACUUM HOSE FOR VGT		I		I		I		I		I
DRIVE BELTS ALTERNATOR			Inspect at 60,000 ; then every 20,000							
ENGINE COOLANT			Replace at 60,000 miles, then every 40,000							
ENGINE COOLANT SPECIFIC GRAVITY		Inspect at 40,000 ; then every 20,000								
COOLING SYSTEM (Leaks and Operation)	I	I	I	I	I	I	I	I	I	I
AUTOMATIC TRANSMISSION OIL		Inspect every 40,000 o; Replace at 160,000								
BRAKE FLUID		Replace at 40,000; then every 40,000								
CLUTCH FLUID		Replace at 40,000; then every 40,000								
VEHICLE ON LIFT										
MANUAL GEARBOX OIL LEVEL		C		C		C		C		C
TRANSFER BOX OIL LEVEL (if applicable)		C		C		C		C		C
REAR AXLE OIL LEVEL (if applicable)		C		C		C		C		C
BRAKE PIPES, HOSES & CONNECTIONS	I	I	I	I	I	I	I	I	I	I
CHECK PROPELLER SHAFT (if applicable)		I		I		I		I		I
SUSPENSION & STEERING SYSTEM	I	I	I	I	I	I	I	I	I	I
FRONT SUSPENSION BALL JOINTS	I	I	I	I	I	I	I	I	I	I
FUEL SYSTEM,TANK & LINES	I	I	I	I	I	I	I	I	I	I
DRIVESHAFTS & BOOTS	I	I	I	I	I	I	I	I	I	I
FLUID LEAKS	I	I	I	I	I	I	I	I	I	I
EXHAUST SYSTEM	I	I	I	I	I	I	I	I	I	I
FRONT & REAR WHEEL BEARINGS		I		I		I		I		I
REMOVE ROAD WHEELS (Lube Wheel Spigots)	I	I	I	I	I	I	I	I	I	I
PARKING BRAKE (Internal Shoe Only)		I		I		I		I		I
FRONT & REAR BRAKE PADS & DISCS,	I	I	I	I	I	I	I	I	I	I
FRONT & REAR TRACK (Visual)	I	I	I	I	I	I	I	I	I	I
CHECK NUT AND BOLTS ON CHASSIS	I	I	I	I	I	I	I	I	I	I
TYRE CONDITION & PRESSURE (Incl. Spare)	I	I	I	I	I	I	I	I	I	I
VEHICLE ON FLOOR										
LUBRICATE LOCKS & HINGES	L	L	L	L	L	L	L	L	L	L
BATTERY CONDITION (Using HMC Battery Tester)	I	I	I	I	I	I	I	I	I	I
CLIMATE CONTROL FILTER		Replace every 20,000								
CHECK AC SYSTEM FOR LEAKS AND COOLING	I	I	I	I	I	I	I	I	I	I
PARKING BRAKE (Adjust, if neccessary)	I	I	I	I	I	I	I	I	I	I
FINAL CHECKS										
ALL ELECTRICAL SYSTEMS	C	C	C	C	C	C	C	C	C	C
OPERATION OF ALL LIGHTS	C	C	C	C	C	C	C	C	C	C
OPERATION OF ALL WARNING LAMPS	C	C	C	C	C	C	C	C	C	C
ALL SYSTEMS WITH GDS	C	C	C	C	C	C	C	C	C	C
ROAD TEST VEHICLE	C	C	C	C	C	C	C	C	C	C

TECHNICIAN NAME		DEALER STAMP
TECHNICIAN SIGNATURE		
QUALITY CONTROL - ROAD TEST (MINIMUM TEST 3 MILES)	MILES COVERED	
TESTER NAME		
TESTER COMMENTS		

